SHAKOTAN HUT KEROSENE STOVE INSTRUCTIONS



STEP 1 – Open the kerosene tank valve, turning the knob vertical.




STEP 2 – Depress the 'Reset' switch down. You'll feel a 'click', and when you let go, the lever will return to its original position.



STEP 3 – Turn the dial to 1. This will cause a very small amount of kerosene to start leaking into the stove.



STEP 4 – Open the small cover to the ignition hole, light a match, and put the burning end of the match inside the ignition hole, up against the nozzle to the right of the entrance, inside the stove.



To extinguish the stove, turn knob all the way clockwise, pull the Reset switch up, and return the kerosene tank valve to horizontal.

